

# Exercise 1: Prepare dataset from Time-of-Flight (ToF) sensor

This exercise shows how to view, process and interpret the data acquired from the VL53L8CX sensor from ST Microelectronics. You will use the logged sensor data in a tabular format and augmented with different rotations and flips.



## Load logged sensor data

Load dataset as table that contain ToFReading, ZonalData and Gesture classifications.


```
load("dataTable_4Class.mat");
% Display selected rows in the table
disp(dataTable([1 3000 end], :));
```

ToFReading	ZonalData	Gesture
{8×8 double}	{8×8 double}	BreakTime
{8×8 double}	{8×8 double}	FlatHand
{8×8 double}	{8×8 double}	Love


```
% set up classes of interests
classNames = categories(dataTable{:, "Gesture"});
```

## Display sample data

```
breaktime_1 = dataTable(1,:);
flathand_1 = dataTable(3000, :);
love_1 = dataTable(end, :);
imgT_tof = imtile({breaktime_1.ToFReading{1}, flathand_1.ToFReading{1}});
imshow(imgT_tof, [], InitialMagnification="fit");
```



```
imgT_zone = imtile({breaktime_1.ZonalData{1}, flathand_1.ZonalData{1}});  
imshow(imgT_zone, [], InitialMagnification="fit");
```



## Augment data with rotations and flips

An image data augmenter configures a set of preprocessing options for image augmentation, such as resizing, rotation, and reflection.

```
imageAugmenter = imageDataAugmenter( ...  
    'RandRotation',[-90,90]);  
  
rotate1 = augment(imageAugmenter,{breaktime_1.ToFReading{1}});  
rotate2 = augment(imageAugmenter,{breaktime_1.ToFReading{1}});  
rotate3 = augment(imageAugmenter,{breaktime_1.ToFReading{1}});  
imgAug_tof = imtile([breaktime_1.ToFReading{1}, rotate1, rotate2, rotate3]);  
imshow(imgAug_tof, [], InitialMagnification="fit", Border="loose");
```



## Perform the data augmentation on all the data

Bring out the training portion of the data and rotate with random angle.

```
imageSize = [8 8 1];  
[xTrain, label_Train, ~, ~] = trainWithTabularData(dataTable);  
% Use augmentedImageDatastore object for training  
augimds =  
augmentedImageDatastore(imageSize,xTrain,label_Train,'DataAugmentation',imageAugment  
er)
```

```
augimds =
```

augmentedImageDatastore with properties:

```
    NumObservations: 4248
    MiniBatchSize: 128
    DataAugmentation: [1×1 imageDataAugmenter]
    ColorPreprocessing: 'none'
        OutputSize: [8 8]
        OutputSizeMode: 'resize'
    DispatchInBackground: 0
```

## Save the original data and augmented data

```
% Save as new dataset
save("dataAugmented.mat"); %name the new variables
```